

User Guide

smartLink HW-PN



Disclaimer of liability

The information contained in these instructions corresponds to the technical status at the time of printing of it and is passed on with the best of our knowledge. Softing does not warrant that this document is error free. The information in these instructions is in no event a basis for warranty claims or contractual agreements concerning the described products, and may especially not be deemed as warranty concerning the quality and durability pursuant to Sec. 443 German Civil Code. We reserve the right to make any alterations or improvements to these instructions without prior notice. The actual design of products may deviate from the information contained in the instructions if technical alterations and product improvements so require.

Trademarks

PROFINET is a registered trademark of PROFIBUS Nutzerorganisation e.V. (PNO)


OpenSource


To comply with international software licensing terms, we offer the source files of open source software used in our products. For details see <https://opensource.softing.com/>

If you are interested in our source modifications and sources used, please contact: info@softing.com

Softing Industrial Automation GmbH

Richard-Reitzner-Allee 6
85540 Haar / Germany
<https://industrial.softing.com>

 + 49 89 4 56 56-340

 info.automation@softing.com
support.automation@softing.com


 <https://industrial.softing.com/support/support-form>



Table of Contents

Chapter 1	About this guide	5
1.1	Read me first.....	5
1.2	Target audience.....	5
1.3	Typographic conventions.....	5
1.4	Document history.....	6
1.5	Related documentation and videos.....	6
1.6	Document feedback.....	6
Chapter 2	About smartLink HW-PN	7
2.1	Intended use.....	7
2.2	Supported features.....	7
2.3	System requirements.....	7
2.4	Technical data.....	8
2.5	Hardware interfaces.....	9
2.5.1	Real-time clock	9
2.5.2	Safety precautions	9
2.6	Software interfaces.....	9
2.6.1	OPC UA	9
2.6.1.1	FDI communication server.....	9
2.7	LED status indicators.....	10
2.7.1	Status LEDs startup phase	11
2.7.2	Status LEDs – factory mode	11
2.7.3	Status LEDs – normal mode	12
Chapter 3	Installation	13
3.1	Hardware installation.....	13
3.1.1	Mounting and dismounting	13
3.1.2	Connections and nameplate	14
3.1.3	Power and alarm connectors	15
3.1.4	Installation positions	16
3.1.5	Connecting to the network	17
3.1.6	Powering up the device	17
3.1.7	Resetting the device	18
3.1.7.1	How to reset the device to factory default.....	18
3.1.7.2	How to restart the factory firmware.....	19
3.2	Software installation.....	21
3.3	Commissioning.....	21
3.3.1	Prerequisites	21
3.3.2	Changing the IP address using the integrated web interface	21
3.3.3	Search and Configure Tool	22

3.3.4	Changing the IP address using the Search and Configure tool	23
3.3.5	Login to user interface	25
3.3.6	Configuring PROFINET	25
Chapter 4	Security	26
Chapter 5	Working with the smartLink HW-PN	27
5.1	User interface.....	27
5.1.1	General functions	27
5.1.2	Information	27
5.1.2.1	System	27
5.1.2.2	License	28
5.1.2.3	About	28
5.1.3	Settings	29
5.1.3.1	Network	29
5.1.3.2	User accounts	30
5.1.3.3	Firmware	32
5.1.3.4	Reset	34
5.1.3.5	Certificates	35
5.1.3.6	Time & date	36
5.1.3.7	Licensing	37
5.1.4	Diagnosis	41
5.1.4.1	Settings	41
5.1.4.2	Log File	42
5.1.4.3	Threads	43
5.1.4.4	Status	43
5.1.4.5	Live List	44
5.1.5	OPC UA	47
5.1.5.1	Identity	47
5.1.5.2	Security	47
5.1.6	PROFINET	49
Chapter 6	Declaration of conformity	50
Chapter 7	Glossary	51

1 About this guide

1.1 Read me first

Please read this guide carefully before using the device to ensure safe and proper use. Softing does not assume any liability for damages due to improper installation or operation of this product.

This document is not warranted to be error-free. The information contained in this document is subject to change without prior notice. To obtain the most current version of this guide, visit the [product website](#).

1.2 Target audience

This guide is intended for experienced operation personnel and network specialists responsible for configuring and maintaining field devices in process automation networks. Before installing and operating the smartLink HW-PN make sure that you have read and fully understood the safety requirements and working instructions in this guide.

1.3 Typographic conventions

The following conventions are used throughout Softing customer documentation:

Keys, buttons, menu items, commands and other elements involving user interaction are set in bold font and menu sequences are separated by an arrow

Open **Start** → **Control Panel** → **Programs**

Buttons from the user interface are enclosed in brackets and set to bold typeface

Press **[Start]** to start the application

Coding samples, file extracts and screen output is set in Courier font type

MaxDlsapAddressSupported=23

Filenames and directories are written in italic

Device description files are located in C:
*<Application name>\delivery\software\Device
Description files*



CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in damage or injury.



Note

This symbol is used to call attention to notable information that should be followed during installation, use, or servicing of this device.



Hint

This symbol is used when providing you with helpful user hints.

1.4 Document history

Document version	Changes since last version
1.00	First version
1.01	<ul style="list-style-type: none">Minor editorial changes
1.02	<ul style="list-style-type: none">Chapter Resetting the device¹⁸ added.New Live List⁴⁴ features.
1.03	<ul style="list-style-type: none">User interface chapters Settings → Certificates³⁵ and OPC UA → Security²⁶ added.

1.5 Related documentation and videos

See the following links for additional and related product information:

- Currently not applicable*

1.6 Document feedback

We would like to encourage you to provide feedback and comments to help us improve the documentation. You can write your comments and suggestions to the PDF file using the editing tool in Adobe Reader and email your feedback to support.automation@softing.com.

If you prefer to write your feedback directly as an email, please include the following information with your comments:

- document name
- document version (as shown on cover page)
- page number

2 About smartLink HW-PN

The Softing smartLink HW-PN provides access to the communication system and connects the higher-level network structure with the field level.

The default configuration allows for a start-up in only a few minutes. In order to prevent network disruptions by unauthorized configuration changes, all configuration functions are protected by user administration.

2.1 Intended use

The smartLink HW-PN is designed to be used as a secure access point to PROFINET networks. Any other use is deemed non-intended use.



CAUTION

Do not use this device in hazardous areas! See Section [Technical Data](#)⁸ for permissible ambient conditions.



Note

Installation and operation of the smartLink HW-PN must be performed by qualified personnel only.

2.2 Supported features

smartLink HW-PN supports the following features:

- access to PROFINET devices
- access to Softing's aplSwitch Field, pnGate PA and pnGate DP
- PLC-independent access to PROFINET networks

2.3 System requirements

To parametrize PROFINET devices with your smartLink HW-PN you will need:

- 18 VDC to 32 VDV power supply
- PC with web browser
- Ethernet cable
- PROFINET cable

2.4 Technical data

Hardware	Processor: Altera Cyclone V SoC with dual-core ARM Cortex-A9 Status LEDs: PWR, RUN, ERR, BUS Real-Time Clock: Real-Time clock with buffering, setting the time via browser or by NTP server (buffer time depends on conditions such as ambient temperature and duration of use)
Interfaces	Ethernet: 1 x IEEE802.3 10BASE-T/100BASE-TX/1000BASE-T, Connector: RJ45 PROFINET: 2 x IEEE802.3 10BASE-T/100BASE-TX, Connector: RJ45 Embedded PROFINET 2-port switch for line or ring topology Protocol: PROFINET RT / IRT, Support of PROFINET redundancy protocols
Supported communication protocols	PROFINET, PROFIBUS, FDI communication server (OPC UA)
Supported PROFINET PROFIBUS Proxies	Softing: pnGate PA, pnGate DP, aplSwitch Field PA
Dimensions (H x W x D)	120 mm x 28 mm x 110 mm
Weight	about 430g
Power Supply	18 VDC ... 32 VDC; SELV/PELV power supply mandatory, typical input current: 200 mA, maximum input current: 1 A (allowing for in-rush current at switch-on)
Typical Power Loss	5 W
Operating Temperature	-40 °C ... +65°C (see also Section Installation Positions ¹⁶)
Storage Temperature	-40 °C ... +85 °C
Relative humidity	10 % ... 95 %, non-condensing
Cooling	Convection, no fan
Mounting	DIN rail 35 mm
Protection	IP20
Altitude	intended use must not exceed 2000 m in altitude
Usage location	indoor use only; no direct sunlight

2.5 Hardware interfaces

2.5.1 Real-time clock

A real-time clock (RTC) is located on the device, which is used to validate the temporal validity when using certificates. The real-time clock is buffered so that the real-time clock continues to run in the event of a brief power failure. The buffer time is limited and depends on various parameters (ambient temperature, duration of use, ...) and can range from a few hours to several days.

During the initial installation and if the power failure lasts longer than the buffer time, the RTC can be set using a browser via the web server (see corresponding section: Setting the RTC via browser).

Therefore, a problem with the validity of a certificate may indicate that the real-time clock is not set. It is recommended to use a time server in the network (NTP server), then the device automatically fetches the current time (see corresponding section: Activating the NTP server).

2.5.2 Safety precautions



CAUTION

During operation, the device's surface will be heated up. Avoid direct contact. When servicing, turn off the power supply and wait until surface has cooled down.



CAUTION

The electronic components of the smartLink HW-PN are sensitive to electrostatic discharges. Damages due to electrostatic discharge can lead to premature failure of components or intermittent faults at a later stage. Before installing the smartLink HW-PN, divert the electrostatic discharge away from your body and the tools used.



Note

Do not open the housing of the smartLink HW-PN. It does not contain any parts that need to be maintained or repaired. In the event of a fault or defect, remove the device and return it to the vendor. Opening the device will void the warranty!

2.6 Software interfaces

2.6.1 OPC UA

The smartLink HW-PN has an OPC UA server integrated. This server implements the TCP based binary OPC UA protocol and allows OPC UA clients to connect to it.

2.6.1.1 FDI communication server

The FDI communication server supports both PROFINET (FCG_TS62769-103-4) and PROFIBUS (FCG_TS62769-103-1) profiles.


The OPC UA server of the smartLink HW-PN complies with the OPC 30080-7 / FCG TS62769-7 specification V1.3 "FDI Communication Devices". This specification can be found on the FieldComm Group web page (www.fieldcommgroup.org) and for download on the OPC Foundation web page (www.opcfoundation.org).

An example of an FDI communication client written in Python is available at:

<https://github.com/SoftingIndustrial/FDICommClient>.

2.7 LED status indicators

smartLink HW-PN has four device status LEDs at the top, two connection status LEDs on the web server port and two on each PROFINET connection port:





PWR = power supply - refer to [next section](#)¹¹

RUN = running - refer to [next section](#)¹¹


ERR = error - refer to [next section](#)¹¹

BUS = configuration - displays configuration upload - refer to [next section](#)¹¹


The device status LEDs are permanently on or flash in different colors and frequencies as indicated below:

Symbol	Color	Light
	none	off
	red	permanent
	green	permanent
	red	flashing (1 Hz)
	red	flashing quickly (5 Hz)
	green	flashing (1 Hz)
	green	flashing slowly (0.5 Hz)
	green	flashing quickly (5 Hz)
	orange (red/green)	permanent
	orange (red/green)	green permanent + red flashing (1 Hz)

















The **Ethernet port LEDs** indicate the following behaviour:

Ethernet port LEDs	Colour	Behaviour
	green	ON when port has an active link
	yellow	FLASHING when there is traffic on the port























The **PROFINET port LEDs** indicate the following behaviour:

PROFINET port LEDs	Colour	Behaviour
	green	ON when port has an active link and FLASHING when there is traffic on the port
	yellow	currently not in use




















2.7.1 Status LEDs startup phase

LEDs				Meaning
PWR 	RUN 	ERR 	BUS 	Power Off – check Power supply.
PWR 	RUN 	ERR 	BUS 	Power On - 24V DC power supply is ok.
PWR 	RUN 	ERR 	BUS 	Start up phase (up to 30 seconds).
PWR 	RUN 	ERR 	BUS 	Start up phase finished – check execution mode (normal or factory).

2.7.2 Status LEDs – factory mode

LEDs				Meaning
PWR 	RUN 	ERR 	BUS 	Device running in factory mode.
PWR 	RUN 	ERR 	BUS 	Firmware update is running.
PWR 	RUN 	ERR 	BUS 	Request to execute factory reset.
PWR 	RUN 	ERR 	BUS 	Device executes factory reset.
PWR 	RUN 	ERR 	BUS n.a	Software error - restart the device.
PWR 	RUN 	ERR 	BUS n.a	Software error - device restarted automatically and error is reported in log file.

2.7.3 Status LEDs – normal mode

LEDs				Meaning
PWR 	RUN 	ERR n.a.	BUS n.a.	Device running in Normal mode.
PWR 	RUN 	ERR n.a.	BUS n.a.	Firmware update is running.
PWR 	RUN 	ERR n.a.	BUS 	Device is configuring for PROFINET.
PWR 	RUN 	ERR n.a.	BUS 	Device joined PROFINET and is online.
PWR 	RUN 	ERR 	BUS n.a.	Software error - restart the device.
PWR 	RUN 	ERR 	BUS n.a.	Software error - device restarted automatically and error is reported in log file.
PWR 	RUN 	ERR 	BUS n.a.	Flash LED operation is running (DCP-Signal).

3 Installation

3.1 Hardware installation



Note

With an ambient temperature above 55 °C at the place of installation it is very likely that the temperatures of connecting cables will increase if the cables are installed in an unfavourable position. In such cases, measure the temperature to ensure that the service temperature of the cables is not exceeded or use cables sustaining high temperatures of at least 90 °C.

3.1.1 Mounting and dismantling



Note

Make sure the smartLink HW-PN is mounted in such a way that the power supply can be easily disconnected. Depending on the installation position, the maximum ambient operating temperature may differ. See Section [Installation positions](#) ¹⁶ for details.



Installation and inspection

Installation and inspection must be carried out by qualified personnel only (personnel qualified according to the German standard TRBS 1203 - Technical Regulations for Operational Safety). The definition of terms can be found in IEC 60079-17.


Mounting

1. Hook the upper notch of the cut-out on the back of the device into a 35 mm DIN rail.
2. Leverage the screwdriver upwards, pull the locking bar downwards and move the device down towards the rail.
3. Press the gateway down towards the rail until it slides into place over the lip of the locking bar.




Note

Do not put stress on the system by bending or torsion.




Dismounting

1. Slide a screwdriver diagonally under the housing into the locking bar.
2. Leverage the screwdriver upwards, pull the locking bar downwards and move the gateway upwards off the rail.



3.1.2 Connections and nameplate

The following diagram shows the interfaces of the smartLink HW-PN. The device has one 1 GBit Ethernet port (ETH) connecting to your IT network and two 100 MBit Ethernet ports connecting to your PROFINET network and PLC. The connectors on the top are reserved for the supply voltage and alarm output. The uSD card slot is used for future service purposes and is not supported in the current version of the product.



3.1.3 Power and alarm connectors

Connect the smartLink HW-PN to a 24 V DC power supply.





Note

smartLink HW-PN is intended for connection to a SELV/PELV circuitry only.

Power connector

The supply voltage (18 VDC 32 VDC) is connected by a 3-pole terminal block. The power supply is connected to the plug connector via flexible wires with a cross section of 0.75 to 1.5 mm². The ground connection wire must have a cross section of 1.5 mm².

	Signal	Description
	24VDC	24 V DC power supply
		Functional earth
	GND	Ground




CAUTION

The Functional Earth (FE) connection of the device has to be connected at low inductance with the Protective Earth (PE) of the system.

Alarm connector

The alarm output has a voltage range of 0-32V. Connect the positive supply voltage with the COM terminal to avoid damage when the connector accidentally mixed up.

	Signal	Description
	NO	Normally Open
	NC	Normally Closed
	COM	Common Terminal

3.1.4 Installation positions

The smartLink HW-PN can be mounted horizontally and vertically. Depending on the installation position, different ambient operating temperatures (T_a) apply.



Minimum distance


Provide a minimum distance of 50 mm to the air inlet and air outlet to ensure natural convection.




Rotated installation position

The maximum permissible ambient temperature values also apply to a 180° rotated installation position.

Horizontal installation position




Vertical installation position



Max. ambient temperature (T_a)	T_a - no distance	T_a at 28mm distance between devices
horizontal	60 °C	65 °C
vertical	50 °C	60 °C

3.1.5 Connecting to the network

1. Connect your PC to the 1 GBit Ethernet (ETH) port of your smartLink HW-PN.
2. Connect your PROFINET network (with its Remote IOs, field devices and PLC) to the Ethernet ports (ETH1 and/or ETH2) of your smartLink HW-PN .



Note

The smartLink HW-PN can also be used in a PROFINET line or ring topology too. In this case it is best to locate it next to the controller.



Note

To access PROFIBUS devices, the PROFINET-PROFIBUS proxies have to be in the same PROFINET network as the smartLink HW-PN .

3.1.6 Powering up the device

Turn on the power supply. The boot process will take about 30 seconds. Refer to [LED status indicators](#)¹⁰ for a detailed description of the LEDs and their behaviour.

3.1.7 Resetting the device

If your smartLink HW-PN is not responding, is malfunctioning or you simply cannot log on to the device because you have forgotten your login credentials you can restore the original factory conditions, remove the existing user data and clear the device settings by performing a hard reset. Licenses will not be affected by the reset and will remain on the device. However, performing a factory reset will clear your device of all parameter settings and configuration data.




Note

We recommend to press the reset button only if you wish to clear your device of all configurations or if you have attempted all other methods of troubleshooting. Remember that the a hard reset will delete all device settings and data added by the user.

3.1.7.1 How to reset the device to factory default

1. Insert the tip of a metal pin, of a pen or the end of an unwound paper clip into the hole of the reset button as shown.




2. Press the reset button very carefully while reconnecting and powering up the device again and hold the button until the [RUN LED](#)¹¹ turns red and is flashing fast.
3. Release the reset button.
The smartLink HW-PN is restarting.
4. Press the reset button and hold for about 15 seconds until the two LEDs in the middle (RUN and ERR) are flashing red.
5. Release the reset button.
When the lights turn off (after about a minute), the smartLink HW-PN is reset and starts in factory mode. First the PWR LED turns yellow. Next the PWR LED turns from yellow to green and the LED RUN turns from red to green.
6. Now update the device with the latest firmware. See Chapter [Firmware update](#)³² for details.


3.1.7.2 How to restart the factory firmware

The smartLink HW-PN device comes with a factory firmware that cannot be deleted or overwritten. When the device detects that the standard user firmware is faulty, it will automatically resort to the factory firmware. However, in the unlikely event that the factory firmware is flawed and the smartLink HW-PN device does not manage to load it automatically, you will have to restart it manually by performing as described below. Licenses will not be affected by the reset and will remain on the device.


1. Disconnect the power supply from the smartLink HW-PN device.
2. Insert the tip of a metal pin, of a pen or the end of an unwound paper clip into the hole of the reset button as shown above.



- Press the reset button very carefully while reconnecting and powering up the device again and hold the button until the [RUN LED](#)¹¹ turns red and is flashing fast.
- Release the reset button.
The smartLink HW-PN is restarting.
- Open your Internet browser and enter the IP address of your smartLink HW-PN to access the user interface. At this point the user interface indicates that it is running in factory mode.



- Select **Settings** → **Choose Firmware File...** to update the firmware of your smartLink HW-PN. See Chapter [Firmware update](#)³² for details.



3.2 Software installation

3.3 Commissioning

The smartLink HW-PN comes with an integrated web server which is used to configure the device. The default IP address of the integrated web server is 192.168.0.10. To change the network settings of the smartLink HW-PN you can either change the IP address of the corresponding network adapter on your PC to access the integrated web server or use the Search and Configure tool. Section 4.2²¹ and Section 4.3²³ describe how to perform either of these two settings.

3.3.1 Prerequisites


- The smartLink HW-PN is connected with a PC which runs a Chrome, Microsoft Edge or Firefox web browser supporting JavaScript.

3.3.2 Changing the IP address using the integrated web interface

You can access the web interface of the smartLink HW-PN by changing the IP address of your PC. Using the web interface you can change the network settings of the smartLink HW-PN afterwards.

The following chapter describes how to set a static IP address in Windows 10.

1. Click **Start → Windows System → Control Panel** from your task bar.
2. Select **Network and Internet → Network and Sharing Center**.
A new window opens where you can view your basic network information.
3. Click on your Internet connection (either Ethernet or wireless) next to Connections under **View your active networks**.
A new window opens.
4. Click **[Properties]**.
5. Select **Internet Protocol Version 4 (TCP/IPv4)**.
The following window opens.



6. Select **Use the following IP address** and enter a specific IP address and Subnet mask. In our example we use the following settings:
IP address: 192.168.0.1
Subnet mask: 255.255.255.0
7. Click **[OK]** to confirm.
8. Adapt the network settings of your smartLink HW-PN as described in Section [Network](#)²⁹.

3.3.3 Search and Configure Tool

You can optionally install the Search and Configure Tool on a Windows PC. This tool detects installed smartLink HW-PNs in a network and allows you to configure their network settings.

When you install a Softing product for the first time, you will be asked if you trust the publisher. Activate the option **Always trust software from Softing AG** if you do not want to be asked in subsequent installations and select **[Install]** to start the installation.

1. Go to the [product website](#) to download the latest Search and Configure*.
2. Start by downloading and installing the **Search and Configure** tool.
3. Follow the on-screen installation instructions.
4. Read the license agreement carefully.
If you have questions, you can **[Cancel]** the installation at this point and contact us. Click **[Print]** if you want to print the license agreement to a PDF or on a printer.
5. Select **I accept the terms in the license agreement** and click **[Next]**.
6. Click **[Install]** to install the selected software application on your PC.
While the installation is in progress, the status bar of the installation wizard shows the different steps that are being executed. If you want to abort the installation, click **[Cancel]** button. The installation wizard will undo all modifications that have been made to your computer up to this point. Otherwise, wait until the installation is completed.
7. Press **[Finish]** to complete the installation and exit the wizard.

**Note**

Proceed with the installation of the other software packages.


* Search and Configure: discovery and IP-Configuration of smartLink HW-PN

3.3.4 Changing the IP address using the Search and Configure tool


Before you can operate the connected smartLink HW-PN you will have to change the default IP address of your gateway so that your PC can communicate with the integrated web server over the Local Area Network.

The following steps apply to Windows 10.


1. Click **Start** → **Softing** → **Search and Configure**.
The application window is opened.



2. Click the dropdown list of the **Network Adapter Selection**.
This selection menu shows all network adapters of your PC.
3. Select the network adapter which is connected to the smartLink HW-PN.
4. Click **[Search]** to start searching for connected devices.
The search may take a moment.



5. Select the smartLink HW-PN.
6. Click **[Configure]** or double-click the device.
The configuration window opens. Here you can change the IP settings.






Note

You may also change the hostname. However, ensure that you follow hostname specifications RFC 952 and RFC 1123.

7. Enter a dedicated IP address and subnet mask or click **Use DHCP** to obtain the IP settings from a DHCP server.
8. Enter the **Password**.
Example: **GEA-YA-026010<serialnumber>**
The serial number can be found on the device, on the packaging and in the Search and Configure tool. See Section [Login to user interface](#) ²⁵ for details.
9. Click **[Submit]**.
The changed settings are written to the device.

3.3.5 Login to user interface

1. Open your Internet browser and enter the IP address of your smartLink HW-PN.
2. Enter **administrator** in the user field and the **password** below (example: *GEA-YA-026010<serialnumber>*). The **default password** (initial or after executing a factory reset) is a combination of the article number and the serial number which you find on the nameplate on the side of the device.



The web-based interface opens with the information page.

3.3.6 Configuring PROFINET

See Section [PROFINET](#)⁴⁹ in Chapter *Working with the user interface* for more details.

4 Security

The smartLink HW-PN is installed in level 0 of the Purdue reference model.

With its three Ethernet ports it resides in 2 network segments:

- The upper Ethernet port ETH is providing Software interfaces for asset management applications running in level 3.
- The PROFINET Ethernet ports (ETH1 / ETH2) it must be part of the level 0 PROFINET network segment.

smartLink HW-PN upper Ethernet (ETH) services

Service	Port	Description
OPC UA	4840 TCP	OPC UA Server Only this port of the device should be accessible from level 3
HTTP	80 TCP	HTTP Server of integrated web server
HTTPS	443 TCP	HTTPS Server of integrated web server

5 Working with the smartLink HW-PN

See Section [Log in to user interface](#) ²⁵ for details on how to access the interface.

5.1 User interface

5.1.1 General functions

All interface windows display the following functions:

Restart Device

This function is available only when logged in as administrator or maintenance engineer and is used to restart the gateway remotely as instructed in this user guide or whenever required in ongoing operation.

Logout

Select this function to log out as an active user.

Auto logout

This default setting logs out the current user from the gateway if the interface has been inactive for 10 minutes.

5.1.2 Information

The **Information** window shows detailed product-related information in the menus **System**, **License** and **About**, including the type of gateway hardware, version, bootloader and firmware of your gateway.

5.1.2.1 System

Select **Information** → **Device/System** to view the hardware and software details of your device.

smartLink	Information	Settings	Diagnosis	OPC UA	PROFINET
Views	Device / System				
System	Serial Number 233800038				
License	Firmware Version 1.02.00.27552				
About	Bootloader Version 2.00.01.24974				
	Factory Version 2.00.00.24974				
	Hardware Version 2.00				
	System ID smartLink HW-PN 2xP				
	Host ID #00-06-71-75-00-E4#0441#0DEF8166#				
	MAC Address 00:06:71:75:00:E4				
	Motherboard				
	Serial Number 233800038				
	Firmware Version -				
	Hardware Version 1.00				

Parameter	Meaning
Serial Number	Serial number of the gateway.
Firmware Version	Version of the currently running firmware.
Bootloader Version	Version number of the boot loader.
Factory Version	Version number of the factory image.
Hardware Version	Version number of the hardware.
System ID	device type = smartLink HW-PN
Host ID	This is the ID you will need to request a licence.

5.1.2.2 License

Select **Information** → **License** to view the licenses used by the gateway firmware under an [open source license](#).

5.1.2.3 About

Select **Information** → **About** to show information about Softing and other useful information.

5.1.3 Settings

5.1.3.1 Network

Select **Settings** → **Network** to view and change the TCP/IP settings.



Note

You need to be logged in as [Administrator or Maintenance](#)³⁰ to change default settings. If you change the settings you must restart the gateway.

Parameter	Meaning
Obtain IP address from a DHCP server	The Dynamic Host Configuration Protocol (DHCP) is activated and the IP address is obtained from a DHCP server.
IP address	Internet Protocol (IP) address of the device used for web access.
Subnet mask	Subnet mask of the device used for web access.
Default gateway	Default gateway of the device used for web access.
Hostname	Name of the device used by a name server.
Enable discover services	Check the box to enable <i>Simple Service Discovery Protocol (SSDP) multicast DNS (mDNS)</i> and <i>SearchAndConfigure</i> .
Apply	Click [Apply] to confirm changes made in this window.

5.1.3.2 User accounts

In this section you will learn how to change accounts and passwords.

1. Select **Settings → User Accounts**.
As **administrator** you can create and delete user accounts and also change passwords.

2. Select a user role in the dropdown menu, assign a user name and enter a **New password** in the corresponding fields according to the password rules.
3. Retype the password in the **Confirm new password** field and click **[Create]** to save the user and password settings.

Password rules

A password must contain between eight and 128 characters, including at least 1 lower case letter, 1 upper case letter, 1 number and 1 special character: !"#\$%&'()*+,-./:;<=>?@[\\]^_`{|}~

Changing the password

1. Enter the user name of the account for which you want to change the password.
2. Enter the **Old password**.
3. Enter the **New password**.
4. Retype the password in the **Confirm new password** field and click **[Change]** to save the new password settings.

Deleting an account

1. Enter the user name of the account which you want to delete.
2. Click **[Delete]** to erase the account settings and all remove the user.

The following table shows the user roles and corresponding permissions:

Permission	Administrator	Diagnostic	Maintenance	Observer
Create and delete accounts	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
Change all passwords	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
Change own password	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Configuring gateway	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Reading configuration	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Reading diagnostics	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Updating firmware	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
Resetting gateway	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
Installing HTTPS certificates	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		



Note

The user role *Diagnostic* is not required for daily operations. It is reserved for internal purposes such as troubleshooting. Softing Support may ask you to add a user with this role to obtain more details of your smartLink HW-PN.


5.1.3.3 Firmware

The gateway comes with pre-installed firmware which is maintained and updated to continuously enhance the functionality of the device. To ensure that your smartLink HW-PN is running the latest firmware version check for the latest version in the Softing [Download Center](#). Bear in mind that the smartLink HW-PN cannot be downgraded to a previous version.

**Note**

You need to be logged in as [administrator](#)³⁰.


1. Download the firmware update to your computer.
When you are downloading from this site for the first time you will have to register yourself in a few steps.
2. Log on to the web server of the smartLink HW-PN.
3. Select **Settings** → **Firmware** in the side bar navigation.
4. Click **[Choose Firmware File...]** and select the file *smartLink HW-PN V1-02.bin* from the firmware update you downloaded.



5. Click **[Update]** to install the latest firmware and **[OK]** in the message window. The update progress is shown beneath the update button.

**Hint**

Click **[Check]** to verify, if the file you have chosen is a valid firmware file.



The system performs a firmware file check. The download starts automatically. When the download is completed the smartLink HW-PN will be rebooted. When the boot process is completed, the RUN LED is ON.

**Note**

After the gateway has rebooted you are automatically forwarded to the login page. If this fails press F5 to reload the web page.

**Note**

If anything goes terribly wrong during the firmware update you can always repeat the firmware update.


5.1.3.4 Reset

Unlike the factory reset (hard reset) described in Chapter [Hardware Installation](#)⁹, this soft reset deletes the configuration of your smartLink HW-PN and restores the factory settings of your gateway.

- 1. Select **Settings** → **Reset** in the side bar navigation
- 2. Select **[Erase Configuration]** to reset your device to default settings.



Note
You need to be logged in as [administrator](#)³⁰.



- 3. Click **[OK]** to confirm your selection.
Your smartLink HW-PN will be restarted with the default settings. License files and IP settings will not be deleted.



Note
The password is reset to the [default password](#)²⁵.

5.1.3.5 Certificates

A certificate is a digital document that is needed to identify and authenticate a website or server and to establish a secure communication (HTTPS) with the OPC UA server of the smartLink HW-PN.

Select **Settings** → **Certificates** to see the smartLink HW-PN X.509 server certificate and load issuer certificates which are used to validate the server certificate. The tables display the subject name and the expiration timestamp of the server and the issuer certificates. The first column either shows a checkmark indicating the certificate's status (✓ = valid, ⚠ = expired/not valid).

In the **Server Certificate** section you can create a new self-signed certificate, upload a new certificate and download the currently installed server certificate or a Certificate Signing Request (CSR). The downloaded server certificate can be passed on to the OPC UA client application to enable secure communication. The CSR can be forwarded to a Certificate Authority (CA) which may create a matching signed server certificate.

If you create a new self-signed certificate or change the existing server certificate, a pencil icon ✎ is shown in the right-most column of the server certificate list (see screenshot below). The icon indicates that the certificate settings have been changed but have not yet been applied and still need to be executed by clicking **[Apply]** in the top right corner.

In addition, intermediate issuer certificates can be uploaded to the **Issuer Certificates** section to configure a chain of trust for the issuer specified in the server or other intermediate certificates.



Note

Ensure that the clock on the smartLink HW-PN is properly set. Otherwise this could result in the creation or usage of certificates that have already expired. See **Settings** → **Time & date** for details.



Note

Your changes are not executed immediately but have to be confirmed by clicking **[Apply]** in the top right corner of the page. This will restart the OPC UA server component of smartLink HW-PN. Any clients connected at that time will lose their connection but typically will automatically reconnect.

5.1.3.6 Time & date

Select **Settings** → **Time & Date** in the side bar navigation to set the time and date of your smartLink HW-PN.

- 1. Click **[Set time from browser]** to synchronize the gateway with the PC date and time manually.
- 2. Click **[Use time server]** and enter the IP address of your time server to synchronize date and time automatically.

smartLink

InformationSettingsDiagnosisOPC UAPROFINET

Views

NetworkUser AccountsFirmwareResetCertificatesTime & DateLicensing

Time & Date

Browser time (UTC)Device time (UTC)

☒ Manual:

2024-07-10 14:31:17

2024-07-10 18:25:02

Set time from browser

NTP Server

☐ Time server:

0.0.0.0

Use time server

Parameter	Meaning
Browser time (UTC)	The time set on the PC.
Device time (UTC)	The time set on the gateway.
NTP server	IP address of a Network Time Protocol (NTP) server used for time synchronisation.
Time server	The time can be set either manually or using a time server.


5.1.3.7 Licensing


Licenses are needed for PROFINET Device Support by any Asset Management Tool to parametrize and monitor PROFINET devices and to retrieve process data and diagnosis data via OPC UA. Each license is tied to one PROFINET slave and can be used for Asset Management and for OPC UA at the same time.

You will most likely have purchased your smartLink HW-PN with one or more PROFINET licenses installed. You will need a license for each field device to which you wish to connect over the PROFINET network. A license is a unique key tied to the serial number of your gateway. It cannot be migrated or run on another smartLink HW-PN.

If your smartLink HW-PN has no license or you wish to connect to more PROFINET devices than previously licensed, please contact Softing Support.

How to activate a license

1. Go to the Softing Industrial website and click the  icon in the upper right corner to register yourself or select this [My Softing Portal](#) link. When you are registered and logged in you are directed to the **My Softing Dashboard**.
2. Select **Licenses** → **Activate License** in the side menu.



3. Enter the license key from your License Certificate in the license key input field. You will find the license key on the certificate you have received by email.

Activate License

Please enter your License Key and your Host ID. If you want to get notified in case of new releases, just check enable release info.

Host ID examples:

BIOS: VMware, Inc. - INTEL - 8040000 | BIOSVMware-564d0191cbe2387-8dc837c83d10ec97
1cf54d56-ce98-3b8a-8a78-125e434899d9
#bd984d56-dc7e-7e47-f262-bfa8d565af0e#
#10-06-71-43-01-CB#123E#0B5ACDE9#

License Key

12345-ABCDE-67890-FGHIJ

Host ID

☐ Enable Release Info

Activate License

Cancel

4. Select **Information** → [System](#) ²⁷.
5. Highlight and copy the Host ID from the Device/System table.
6. Paste the Host ID into the **Host ID** field of the Activate License form.
7. Click **[Activate License]**.
A license file is generated and downloaded to your PC.




Note

The license file is assigned to the device and can therefore only be used with this device.

How to install a license

To install a license file follow these steps:


1. Select **Settings** → **Licensing** in the side bar navigation.



2. Click the **[Choose License File]** button.
Windows Explorer (file explorer) will open.
3. Go to the directory to which you have saved the file.
4. Select the license file and click **[Open]** in Windows Explorer.
The license file is now shown under the [Choose License File] button.
5. Click the **[Install]** button.
When the license has been installed, the following message appears at the bottom of the window.

Update License Info 1055: The license has been successfully updated.

In the Licensing window, the table entries for PROFINET Device Support will have changed.



Parameter	Meaning
Version	A support number (for internal use only).
Options	Total number of supported PROFINET devices.
End date	The date on which the license expires. Generally all licenses are unlimited.
Description	Before a license is installed, this field displays the order number for a license for this specific gateway.

Status	Before a license is installed, this field displays "not installed". When a license has been installed it shows "restart required" against a yellow background. After the gateway has been restarted it shows "installed" against a green background
--------	--

6. Click **Restart Device** in the top menu of the window.
The following message will appear.

smartLink HW-PN

smartLink HW-PN will be restarted.
All applied configuration data will be used.
Continue and restart?

OKCancel

7. Click **OK**.
Now the status column will show "installed" meaning the license is activated on your smartLink HW-PN device.

Views

Network
User Accounts
Firmware
Reset
Certificates
Time & Date
Licensing

Licensing

Name	Version	Options	End date	Description	Status
PROFINET Device Support	2	"10"	unlimited		installed

Choose License File...

License File: No file selected.

Install

5.1.4 Diagnosis



Note

The submenus **Settings**, **Log File**, **Threads** and **Status** are of particular interest for Softing Support.

5.1.4.1 Settings

Select **Diagnosis** → **Settings** to view logging settings. The settings can be viewed in any role. To change the settings you must have administration rights.

Parameters/Actions	Meaning
Log File Priority	Available values: EMERGENCY, ALERT, CRITICAL, ERROR, WARNING, NOTICE, INFORMATION. All messages with the set priority or higher are logged. The log file is shown under Diagnosis → Log File
Log File Facility	Tick the checkbox for the protocol layer you wish to write to the log file.
Send Syslog Messages	Enables additional Log File Priority DEBUG and sends the information to the network. The syslog can be logged with wireshark, Visual Syslog Server or similar.
Syslog Priority	Available values: EMERGENCY, ALERT, CRITICAL, ERROR, WARNING, NOTICE, INFORMATION. All messages with the set priority or higher are logged.
Syslog Facility	Tick the checkbox for the protocol layer you wish to write to the syslog file.
Apply	Click [Apply] to save your changes in the system. If you do not click apply the changes will not be saved.

5.1.4.2 Log File

Select **Diagnosis** → **Log File** to view the log file. You can also filter the diagnostic log by ticking and unticking the checkboxes for each notification priority. Filtering only affects the display of the log and not the log file priority set under **Diagnosis** → **Settings**.

smartLink

InformationSettings**Diagnosis**OPC UAPROFINETRestart DeviceLogout administratorAuto logout in 9 min

optimize softing

Views

Settings

Log File

Threads

Status

Live List

Log File

Refresh10 sClearSupport Data

☒ EMERGENCY☒ ALERT☒ CRITICAL☒ ERROR☒ WARNING☒ NOTICE☒ INFORMATION☒ DEBUG

Severity	Facility	Timestamp (UTC)	Message
INFORMATION	APPL(1)	2022-02-16 06:12:12.133799	CNwicPnslm0StationExplorer::ProcessStateReadImFilterData: Representing module found
ERROR	APPL(1)	2022-02-16 06:12:12.133894	CNwicPnslm0StationExplorer::CreateReadIm0RecordTask: instance=1
ERROR	SCAI(19)	2022-02-16 06:12:12.277368	<SCAI> Trace scai_pn_handle_pending_service_req_res
INFORMATION	SCAI(19)	2022-02-16 06:12:12.277449	<SCAI>[Channel 0] Device 0 implicit_read.req
INFORMATION	SCAI(19)	2022-02-16 06:12:12.283390	<SCAI>[Channel 0] Device 0 implicit_read.con (+)
INFORMATION	APPL(1)	2022-02-16 06:12:12.284420	CNwicPnslm0StationExplorer::DoStateProcessing: _state: 3
ERROR	SCAI(19)	2022-02-16 06:12:12.427370	<SCAI> Trace scai_pn_handle_pending_service_req_res
INFORMATION	SCAI(19)	2022-02-16 06:12:12.427447	<SCAI>[Channel 0] Device 0 implicit_read.req



Note

If you are facing problems with your smartLink HW-PN, use the button **[Support Data]** to create a support file. The information contained in this file helps Softing Support address and fix potential issues.

Parameters / Actions	Meaning
EMERGENCY; ALERT, CRITICAL, ERROR, WARNING, NOTICE, INFORMATION, DEBUG	Tick the check boxes to set a display filter.
Clear	Click this button to delete the log file entries.
Refresh	Click this button to update the message log entries based on the filter settings.
Support Data	Click this button to upload a collection of all available logs for support requests.

5.1.4.3 Threads

Select **Diagnosis** → **Threads** to view the current state of the threads. The list you will see and the details contained may not be of any use to you but helps Softing support to diagnose device and performance errors.

smartLink		Information	Settings	Diagnosis	OPC UA	PROFINET	Restart Device	Logout administrator	Auto logout in 9 min	optimize! softing
Views		Threads								
Settings										
Log File										
Threads										
Status										
Live List										
Id		Name	State	Set Priority	Current Priority	Stack Base	Stack Size	Stack Used		
1		Idle Thread	RUNNABLE	31	31	0x035F9C88	2048	248		
2		Idle Thread	RUNNABLE	31	31	0x035FA488	2048	248		
3		Clock mgmt	SLEEP	20	20	0x0360CE30	7936	536		
4		main	SLEEP	10	10	0x035FB658	12000	2876		
5		FG-2xx led	SLEEP	30	30	0x00B270A4	4096	396		
6		jffs2 gc thread	RUNNABLE	30	30	0x036D3C00	4096	1296		
7		FG-2xx jffs	SLEEP	30	30	0x01A29C5C	16384	364		
8		SysLog	RUNNABLE	30	30	0x03607A8C	4096	1596		
9		FG-2xx ecc	SLEEP	30	30	0x01A427F4	4096	228		
10		FG-2xx firmware	SLEEP	27	27	0x01A282AC	4096	292		
11		FG-2xx capture	SLEEP	27	27	0x01A5050C	4096	236		

5.1.4.4 Status

Select **Diagnosis** → **Status** to view gateway diagnostics.

smartLink		Information	Settings	Diagnosis	OPC UA	PROFINET
Views		Status				
Settings						
Log File						
Threads						
Status						
Live List						
Uptime		12:11:53				
CPU Load (0.1s)		12 % / 7 %				
CPU Load (1s)		11 % / 9 %				
CPU Load (10s)		6 % / 5 %				
CPU IRQ (0.1s)		100 / 11				
CPU IRQ (1s)		133 / 42				
CPU IRQ (10s)		128 / 38				
RAM size		480 MB				
RAM static		54.801 MB				
RAM dynamic used		270.586 KB				
RAM dynamic free		424.934 MB				
Current Temperature		40.5 °C				

5.1.4.5 Live List

Select **Diagnosis** → **Live List** to see a table with all PROFINET, APL and PB devices connected to Softing APL switches, pnGate PA or pnGate DP devices. The table is organized top-down in blocks from general status information to PROFINET and PROFIBUS devices details.

The screenshot displays the 'Live List' interface with the following components and callouts:

- 1**: General scan information at the top, including 'Last scan cycle finished at 19:30:43 and took 23 seconds', '17 Device(s) - 17 Licensed - 79 License(s) remaining', and buttons for 'Reassign Licenses', '100 %', and 'Start Scan'.
- 2**: Summary of PROFINET scans: '13 PROFINET device(s) - 13 Licensed', 'Status: OK', with a PROFINET icon and a collapse/expand arrow.
- 3**: Details of PROFINET scans table with columns: Name, Type, Tag Function, Tag Location, IP Address, MAC Address, Vendor, Device Type, HW Revision, SW Revision, and Status. The table lists various devices like 'apswitch-a', 'pn4-et200sp-1', 'pn4-phoenix-ctrl', etc.
- 4**: Summary of PROFIBUS scans: '4 PROFIBUS device(s) - 4 licensed', 'Status: A child component has an error', with a PROFIBUS icon and collapse/expand buttons.
- 5**: Details of proxies section: 'Proxy apswitch-a: 1 Module(s) - 2 PROFIBUS device(s) - 2 licensed', 'Status: OK', with a table showing proxy details like Address, Tag Function, Tag Location, Vendor, Device Type, HW Revision, SW Revision, and Status.
- 6**: Details of another proxy section: 'Proxy pngatepa-2x: 1 Module(s) - 2 PROFIBUS device(s) - 2 licensed', 'Status: A child component has an error', with a table showing proxy details.
- 7**: A scroll bar on the right side of the interface.
- 8**: A button labeled 'Collapse All' next to the PROFIBUS summary header.

- 1 Results of the last scan:** The general information includes the timestamp and the duration of the last completed scan, the total number of detected and licensed devices and the number of remaining licenses.
- 2 Summary of PROFINET scans:** This header represents the number of detected and licensed PROFINET devices. PROFINET device details can be hidden and displayed by clicking the arrow icon (▼) to the left of the header text. If the PROFINET communication is not working correctly or an error occurred while scanning one of the PROFINET devices, the Status shows an error icon ⚠.
- 3 Details of PROFINET scans:** The table lists the characteristic device properties such as name, type, function, location, IP address or MAC address. If a scanned device has an error, this is indicated by an error icon ⚠ in the leftmost column and an error message displayed in Status field. The PROFIBUS icon (P) in the Type column indicates that the device has a PROFIBUS segment. By clicking the icon the corresponding proxy section and PROFIBUS device table is displayed.
- 4 Summary of PROFINET-to-PROFIBUS proxy scans:** This header sums up the number of detected and licensed PROFIBUS devices. If a child component (any underlying PROFINET-to-PROFIBUS proxy) shows an error this is indicated in the header information.
- 5 Details of proxies:** The header view shows all proxies with a PROFIBUS segment.

- ⑥ **Details of PROFIBUS devices:** The table includes all successfully scanned PROFIBUS devices with additional properties such as channel number, tag function and location, vendor, device type, hardware and software revision numbers, status. To the left of the device name you may see one of the following icons:

✔ = device is licensed and ⚠ = error occurred during scan of the PROFIBUS device

⑦ **Reassign licenses**

By clicking **[Reassign Licenses]** you can reassign all available licenses. This will entail a restart of your smartLink HW-PN

Scan progress bar (%)

Indicates the progress of a running scan process.

Start Scan

A scan is started cyclically once per minute. By pressing this button you can invoke a manual scan. When a scan is in progress this button is disabled.

⑧ **Collapse All**

Hides all tables with details of connected PROFIBUS devices.

Expand All

Expands all tables with details of connected PROFIBUS devices.

PROFINET table column headers explained

Column Header	Meaning
Name	The device name of the PROFINET device
Type	Indicates if the PROFINET device has a proxy functionality. If so, a corresponding icon is displayed. By clicking on the icon you are navigated to the corresponding proxy section.
Tag Function	Displays the Tag Function contained in the device.
Tag Location	Displays the Tag Location contained in the device.
Address	The Internet Protocol Address is a set of four numbers separated by periods identifying a device in your network.
MAC Address	The Medium Access Control Address is the unique 12-digit hexadecimal device number assigned by device manufacturer.
Vendor	This column displays in brackets the manufacturer Identification code as a hexadecimal value. A vendor name is shown only if this value can be resolved.
Device Type	Displays the type of the PROFINET device as a hexadecimal value.
HW Revision	Displays the hardware revision of the PROFINET device.
SW Revision	Displays the software revision of the PROFINET device.
Status	It is either shown as "OK" (when a PROFINET device has been successfully scanned) or with a red error text describing the error detected during the scan process.

PROFIBUS table column headers explained


Column Header	Meaning
Address	Displays the address of the PROFIBUS device.
Tag Function	Displays the Tag Function contained in the device.
Tag Location	Displays the Tag Location contained in the device.
Vendor	This column displays in brackets the manufacturer Identification code as a hexadecimal value. A vendor name is shown only if this value can be resolved.
Device Type	Displays the type of the PROFIBUS device as a hexadecimal value in brackets. A device type name is shown if this value can be resolved.
HW Revision	Displays the hardware revision of the PROFIBUS device.
SW Revision	Displays the software revision of the PROFIBUS device.
Status	It is either shown as "OK" (when a PROFIBUS device has been successfully scanned) or with a red error text describing the error detected during the scan process.

5.1.5 OPC UA

All FDI-related instances have a NodeId with a string identifier. These are located in the OPC UA server application name space index 1.


5.1.5.1 Identity

Select **OPC UA → Identity** to see the server endpoint. In the current version of the smartLink HW-PN the server endpoint has the default port 4840, which cannot be changed in the user interface.





5.1.5.2 Security

Select **OPC UA → Security** to configure a secure communication between the smartLink HW-PN (OPC UA server) and the OPC UA client application.



In the **Security Configuration** window frame, smartLink HW-PN offers three encryption modes supported by three security policies for secure OPC UA communication:



If you have changed any of the security configuration setting, a pencil icon  is shown to indicate that the settings have been changed but have not yet been applied and the the changes still need to be executed by clicking **[Apply]** in the top right corner.

Message Security Modes	Meaning
None	Don't use any encryption. No certificate exchange is needed between smartLink HW-PN and a client. Be aware that communication on the network is readable by others. This might be a security risk.
Sign	Messages sent from smartLink HW-PN or the OPC UA client are signed with the private key of the sender. The receiving entity can validate the origin of the message using the public key of the sending entity. Nevertheless, messages are not encrypted.
Sign and Encrypt	Message are signed as in the Sign mode and additionally encrypted with the public key of the receiving entity. On the receiver side the message can be decrypted using its private key.

If you check **None**, no security policy must be selected. For the modes **Sign** and/or **Sign and Encrypt** at least one policy must be chosen. Although any combination of modes and policies is possible, it is recommended to restrict the configuration to the one that the OPC UA client application is expected to use. For further details see the documentation of the client application.

To establish a secure OPC UA communication smartLink HW-PN and the OPC UA client application have to exchange their public keys. For this they store a certificate of the communication partner in their Public Key Infrastructure (PKI). The OPC UA client application typically receives the public key of smartLink HW-PN by calling the OPC UA service **GetEndpoints**. Alternatively, it can be exported from smartLink HW-PN (**Settings** → **Certificates** → **Server Certificate** → **Download**) and imported manually in the client application. See also the OPC UA client application documentation for more information on how to store the smartLink HW-PN certificate in the **Trusted** section of its PKI.

The **Certificate Management** window frame shows all certificates that are trusted or have been rejected (as a result of a unsuccessful connection attempt from the client application). When an OPC UA client application attempts to open a secure connection to a smartLink HW-PN it submits its client certificate. smartLink HW-PN stores this certificate in the **Rejected Client Certificates** table (see screenshot above). Before a connection between the smartLink HW-PN and the client can be established you have to confirm that you trust this certificate. If the certificate is available as a file, you may upload it directly to the **Trusted Client Certificates**.

The tables include the subject name and the expiration timestamp of each certificate. The first column either shows a checkmark indicating that the certificate's status (✓ = valid, △ = expired/not valid). You can upload new or delete existing client certificates to the **Trusted Client Certificates** and move client certificates from the **Rejected Client Certificates** table the **Trusted** section or simply delete them from the PKI.



Note

Your changes are not executed immediately but have to be confirmed by clicking **[Apply]** in the top right corner of the page. This will restart the OPC UA server component of smartLink HW-PN. Any clients connected at that time will lose their connection but typically will automatically reconnect..

For a detailed view of the common client certificate properties, select and highlight a certificate in either table as shown in the screenshot above (example certificate: *ctt_appT*).

5.1.6 PROFINET

1. Select **PROFINET** → **Settings** to enter the IP settings of your PROFINET network.
2. Click **[Apply]** to confirm and activate your settings.
3. Select Restart Device in the menu bar to activate the new IP settings.

6 Declaration of conformity

This device is compliant with EC directive 2014/30/EG, "Electromagnetic Compatibility" (EMC directive) and meets the following requirements:

- EN 55011 Industrial, scientific and medical (ISM) devices - radio disturbance - limits and methods of measurement
- EN 55032 Electromagnetic compatibility of multimedia equipment (MME) and interference emission
- EN 61000-6-4 Electromagnetic compatibility (EMC); Part 6-4: generic standard – emission for industrial environments
- EN 61000-6-2 Electromagnetic compatibility (EMC); Part 6-2: generic standard - immunity for industrial environments



Note

To fulfill the EMC requirements, the other components of your installation (DC adapter, Industrial Ethernet devices, etc.) also have to meet the EMC requirements. A shielded cable must be used. In addition, the cable shield must be grounded properly.



CAUTION

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures!



CE

The CE marking indicates conformity with the above standards in a Declaration of Conformity which can be requested from Softing Industrial Automation GmbH.



RoHS

This product is compliant the Restriction of Hazardous Substances under Directive 2002/95/EC.



FCC

This equipment has been tested and found to comply with the limits for a Class A digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.



VCCI

This Class A product conforms to the regulations of Voluntary Control Council for Interference (VCCI) by Information Technology Equipment.



WEEE

Electrical and electronic equipment must be disposed of separately from normal waste at the end of its operational lifetime in compliance with Waste Electrical & Electronic Equipment (WEEE) Directive 2002/96/EC. Packaging material and worn components shall be disposed of according to the regulations applicable in the country of installation.


7 Glossary

Abbreviations	Definition
CA	Certificate Authority
CSR	Certificate Signing Request
DHCP	Dynamic Host Configuration Protocol
DIN	Deutsches Institut für Normung
DP	Decentralised Peripherals
ETH	Ethernet
Ex	Explosion protection
FDI	Field Device Integration
GND	Ground
HTTPS	Hypertext Transfer Protocol Secure
I/O	Input/Output
IP	Internet Protocol
NTP	Network Protocol Time
OPC UA	Open Platform Communications Unified Architecture
PA	Process Automation
PKI	Public Key Infrastructure
PLC	Programmable Logic Controller
PN	PROFINET
pnGate	Softing PROFINET Gateway
RIO	Remote Input / Output
RTC	real-time clock
T	Temperature

Softing Industrial Automation GmbH

Richard-Reitzner-Allee 6
85540 Haar / Germany
<https://industrial.softing.com>

 + 49 89 45 656-340

 info.automation@softing.com

