



F&F Filipowski sp.k., ul. Konstantynowska 79/81, 95-200 Pabianice, tel.: +48 (42) 214 90 37, e-mail: biuro@fif.com.pl, www.fif.com.pl



TOM-125-5

Mini Current Transformer 125-5A

Index: TOM-125-5

Single-phase.

With open core.

Transformer 125/5.

Power 1.5 VA.

The current transformer is used to proportionally change large current intensities to lower values, adapted to the measuring ranges of control and measuring devices.

CE  5902431675770

FUNCTIONING

DESCRIPTION

The conductor with the measured current passes through the main bore of the transformer (P1/P2). This is equivalent to one winding of the primary winding. The terminals of the secondary winding S1 and S2 are connected to the terminals of the measuring circuit of the control or measuring device.

The ratio of the currents in the two windings is a constant quantity.

This is the current ratio $I_{Pn}/I_{Sn}=N$, where

I_{Pn} - rated primary current;

I_{Sn} - rated secondary current;

N - gear ratio value.

From the value of the current flowing through the secondary winding, the value of the current flowing through the primary winding can be determined:

$I_{Sm} \cdot N = I_{Pm}$, where

I_{Sm} - measured secondary current;

I_{Pm} - measured primary current.

NOTE

Recommended connection of the secondary system with a wire of not less than 2.5 mm² in diameter.

Recommended earthing of terminal S2.

It is forbidden to disconnect the secondary circuit during the operation of the transformer (possibility of high voltage resulting in shock to persons or damage to the equipment).

TECHNICAL DATA

Number of primary inputs	1
Rated secondary apparent power	0 VA
Rated secondary current	5 A
Rated primary current	125 A
Model	Attachable current transformer
Calibrated	No
With contact protection	Yes
Height opening	0-24 mm
Width opening	0-23 mm
Snap mounting	No
With copper rail	No
Accuracy class	1
Overcurrent limiting factor	FS 5
Secondary connection	Screw connection
Opening diameter	0 mm
Power consumption	0 W

CE Declaration